



USB / RS485 converter part number: 21490-1-0174.

A MODBUS over serial line cable must be shielded. At one end of each cable its shield must be connected to protective ground.  
 An RS485-MODBUS must use a balanced pair (RSA / RSB) and a third wire (GND). AWG 24 is always sufficient for the MODBUS data.

ebm-papst A&NZ Pty Ltd  
 10 Oxford Road Laverton North VIC 3026  
 Ph: (03) 9360 6400 Fax: (03) 9360 6464  
 email:sales@ebmpapst.com.au  
[www.ebmpapst.com.au](http://www.ebmpapst.com.au)